

Unit Replacement: 1S Motor

Steps

- ① Turn OFF the power supply and replace the motor.
- ② Turn ON the power supply and go online.
- ③ Open the [Motor and Encoder] Tab Page.
- ④ Open the [Encoder Properties] screen.
- ⑤ Execute [Reset Motor Replacement Detection error].
- ⑥ Execute [Clear system].
- ⑦ Execute homing.

Detailed Steps


① Turn OFF the power supply and replace the motor.

② Turn ON the power supply and go online.

Go online with the Controller to which the Servo Drive is connected by referring to "[Going Online with an NJ/NX Controller](#)".

③ Open the [Motor and Encoder] Tab Page.

Right-click the Servo Drive connected to the motor that has been replaced from [Configurations and Setup] - [EtherCAT] in the Multiview Explorer, and select [Motor and Encoder].



④ Open the [Encoder Properties] screen.


Click the button shown in the red frame in the figure below to open the [Encoder Properties] screen.

Motor Properties	
Name	Value
Motor ID	R88M-1M100305-BS2
Serial Number	04190800778
Capacity	100 W
Speed	3000 r/min
Voltage	100V
Encoder	Absolute (23 bit resolution)

⑤ Execute [Reset Motor Replacement Detection error].

After replacing the motor, "95.05: Motor replacement detection" error occurs, so execute [Reset Motor Replacement Detection error].

After executing the reset, a pop-up window as shown in the figure below will be displayed, so click the [Yes] button.




* LED indication of the Servo Drive when "Motor replacement detection" error occurred




⑥ Execute [Clear system].

To clear the multiple rotation data, click the [Clear system] button.



After executing the reset, a pop-up window as shown in the figure below will be displayed, so click the [Yes] button.



⑦ Execute homing.

When the motor is replaced, the motor-specific zero position (Z-phase) will shift, so it is necessary to execute homing. Execute homing according to the equipment specifications.

Remarks