

Variable Display Mode and Simulation Mode


Steps

This section introduces the functions useful for checking the touch operation and changes in the screen.


- ① Open the screen you want to check.
- ② Variable Display Mode (Displays the variables assigned to the object.)
- ③ Simulation Mode (Changes to the screen of each object when the state of the object changes.)

Detailed Steps

- ① **Open the screen you want to check.**
An example of the screen is shown below. The screen changes when each button is pressed.
Left red square: Variable Display Mode button
Right red square: Simulation Mode button



- ② Variable Display Mode (Displays the variables assigned to the object.)**
When this button is pressed, the variables assigned to the object are displayed.



③ Simulation Mode (Changes to the screen of each object when the state of the object changes.)

