

# Backing Up 1S/G5 Parameters

## Steps

This section describes the steps for backing up the 1S/G5 Servo Drive individually.

- ① Upload the Servo Drive parameters to the Sysmac Studio.
- ② Click the [Export] icon.
- ③ Select the destination to save it and save.


## Detailed Steps

### ① Upload the Servo Drive parameters to the Sysmac Studio.

Upload the Servo Drive parameters by referring to “[Uploading 1S/G5 Parameters](#)”.


### ② Click the [Export] icon.

Click the [Export] icon shown in the red frame below.



### ③ Select the destination to save it and save.

Select the destination to save the file, enter a file name, and click the [Save] button.



## Remarks

If you want to use a backup file, import the target file using the [Import] icon shown in the red frame below.

